

Xamelo 100

© 2014 NEXT! s.c. S.Piela, B.Dryja

Xamelo 100

© 2014 NEXT! s.c. S.Piela, B.Dryja

All rights reserved. No parts of this work may be reproduced in any form or by any means - graphic, electronic, or mechanical, including photocopying, recording, taping, or information storage and retrieval systems - without the written permission of the publisher.

Products that are referred to in this document may be either trademarks and/or registered trademarks of the respective owners. The publisher and the author make no claim to these trademarks.

While every precaution has been taken in the preparation of this document, the publisher and the author assume no responsibility for errors or omissions, or for damages resulting from the use of information contained in this document or from the use of programs and source code that may accompany it. In no event shall the publisher and the author be liable for any loss of profit or any other commercial damage caused or alleged to have been caused directly or indirectly by this document.

Printed: maj 2014 in (whereever you are located)

Document version 1.0.6

3

TABLE OF CONTENTS

Chapter	1 Introduction	4
Chapter	2 Safety instructions	5
Chapter	3 Description	6
Chapter	4 Xamelo 100 Parameters	7
Chapter	5 Device connection	10
Chapter	6 SIO Extensions Module	11
1	Power supply via SIO extension module	13
Chapter	7 System installation	14
1	Windows CE installation	15
2	Linux installation	19
Chapter	8 Device configuration	19
Chapter	9 Technical information	20
1	Xamelo 100	21
2	SIO	22
3	Norms	23

1 Introduction

Xamelo 100, together with its optional extension modules, is an innovative device designed for the monitoring and security market. Its basic function is to gather and transmit signals from various sources to a central control system, as well as enabling interaction between the central control system and devices connected to Xamelo 100. The device functions depend on the software installed, which in contrast to traditional solutions, are not an integral part of the device itself. This solution provides a wide spectrum for possible adaptation of the device to the specific demands of the user.

Xamelo 100 should be considered as an industrial computer designed for monitoring, but with intelligent routing functions and equipped with a range of standard input/output ports. The device meets all required norms for security systems and alarm transmission devices.



Main board

5



Extension module - Security Interface One (SIO)

2 Safety instructions

This documentation uses the following symbols:



Before using the device please read the safety instructions below.

Incorrect operation or improper use of the device may cause serious damage to the device itself, or may result in injury.

The manufacturer takes no responsibility for any damage or injury caused by incorrect operation or improper use of the device.

- The device should be installed in its casing and kept in dry conditions.
- Device installation must ensure sufficient ventilation to prevent overheating.
- The ventilation holes must meet the following conditions:

 there should be no ventilation holes on the bottom of the casing
 holes of maximum 1mm diameter should be located on the top or sides of the casing
- The casing should only enable access to the battery compartment with the use of tools.
- The device must not be subject to extremes of temperature, humidity, vibration, shock or impact.
- Before use place the device on a stable, flat surface.
- Before connecting the device, ensure the GSM antenna is connected, as the device may be damaged if the antenna is not connected.
- Before connecting ensure that the power supply is connected correctly.

- Switch off the power before connecting any peripheral devices via the COM1-COM4 interfaces.
- Before using the device ensure that the user has no electrostatic charge by touching an earthed metal object.
- Ensure the device does not come into contact with any liquids as this may damage the device or may result in electric shock.
- The SD card must not be removed while the device is in use as this may damage the device or cause it to malfunction.
- The device clock battery should be installed according to the manufacturer's specifications.
- The battery should only be changed with the power supply switched off and the LAN and WAN ports disconnected.



Caution! The device may explode if a battery of the wrong type is used. Dispose of used batteries in the appropriate manner.



Lithium batteries should be recycled or disposed of according to national and local laws and regulations. To avoid fire or explosion, the batteries should not be

exposed to naked flames.

If any of the following should occur, the device should be returned to the manufacturer:

- the device has come into contact with liquid
- the device has been subject to high humidity
- the device does not work properly, or it is impossible to start up the device following the instructions of use
- the device was dropped and damaged
- the device has clear signs of damage

3 Description

The main Xamelo 100 module is a miniature single board computer equipped with a powerful ARM9 processor, 64MB RAM memory, and 512MB NAND Flash memory.

The computer has the following communication interfaces:

- 1 x port USB 2.0 host
- 1 x port USB 2.0 device
- 3 x port RS232
- 1 x port RS485
- 1 x WAN 10/100Mbps
- 4 x LAN 10/100Mbps
- 4 NO/NC input
- 1 OC input

7

- a GPIO/I2C data bus for additional extension modules
- 1 x SD card slot
- GSM/GPRS 850/900/1800/1900 MHz Quectel M10 modem

The devcie is equipped with a GSM/GPRS modem with a SIM card slot, with the option of connecting a microphone and speaker, and the option of following PPP, TCP/IP, HTTP, FTP, MMS internet protocols.

The computer works using:

- Adeneo Embedded® Board Support Package (BSP), Copyright 2009 Adeneo. All Rights Reserved. This includes the Windows Embedded CE 6.0 R3 operating system and BIOS
- Distribution, Linux Angstorm, Kernel: 2.6.30



The computer <u>does not have</u> a graphics interface, access to the device is provided via communication interfaces.

Using a GPIO data bus the main module can work with extension modules.

The Security Interface One (SIO) extension module is an optional module which provides the basic interfaces that allow Xamelo 100 to be used as an independent security system for the protection of premises. These interfaces include:

- 12 input ports for alarm system sensors
- 4 output ports for transmission
- 2 Wiegand ports



Device functionality depends on the software installed and is described in separate instructions of use.

4 Xamelo 100 Parameters

The Xamelo 100 comes equipped with:

- the Xamelo 100 device
- Maxell CR2032 batteries
- an SD card
- device instructions

Layout of the Xamelo 100 device interfaces:



Name	Description
POWER +/-	Direct current 10V ÷ 24V, average/max current - 0,5A/0,7A
WAN	External LAN network interface
USB	USB interface for additional devices
LAN1-4	Internal LAN network interface
SIM Card	Full size SIM card slot
GSM Antenna	GSM modem SMA antenna socket
COM1-3	RS232 interfaces for integrated devices
COM4	RS485 interface for integrated devices via an RJ11 port, (active pins 3 and 4)
Reset	Device reset button
Function Key	Programmable function button
l1 - l4	Programmable NO/NC ports
O1	Programmable OC output, maximum load 50mA
USB Service	USB Device interface for connecting devices to the computer for servicing
SD Card	SD card slot (max 4GB)
BATTERY	3V CR2032 device clock battery socket
Extension Slot	GPIO/I2C data bus for additional extension modules
Service Slot	20 pin JTAG service socket for programming the device processor
Memory Lock RS485 Terminator	Lack of jumper switches the processor into programming mode According to standards, an RS485 terminator should be installed at either end of the line na obu brzegach linii Socket for connecting an external microphone to the GSM modem
Micropriorie	Source for connecting an external microphone to the Gow modelin

© 2014 NEXT! s.c. S.Piela, B.Dryja

Speaker Socket for connecting an external speaker to the GSM modem

Socket for connecting the Power, Error, LAN and GSM diodes on the outside LED of the casing

Jumper JP2 Not used

Jumper JP4 Not used

A

Diode	Diode colour	Status	Description
POWER EBROR LAN GOM	POWER (green)		Correct device operation
POWER ERROR LAN GEM	ERROR (red)		Internal software problem
POWER ERROR LAN GEM	LAN (orange)		Correct connection via WAN
POWER EREOR LAN GEM	GSM (orange)	·····	Correct connection via GSM modem

The meaning of the diode descriptions above may vary depending on the system version and on the software.

Diode	Diode colour	Status	Description
Modem Status			Modem not working
		(64ms on / 800 off)	Modem not synchronized with the network
Modem Status	YELLOW	(64ms on/ 200 off)	Modem synchronized with the network
		(64ms on/ 600ms off)	Data transfer via GPRS in progress

Diode	Diode colour	Status	Description
1 2 Internal LAN			Additional LAN (Internal) inactive due to lack of drivers

1 2 Internal LAN	GREEN	Data transfer in progress
1 2 Internal LAN	ORANGE	Connecting

5 Device connection

Before connecting the device, read the Safety instructions.



The device is not designed to be installed outside. The antenna, and distribution and telecommunication cables cannot be subjected to power surges.

Before starting up the device, ensure the GSM antenna is connected, and the SD card and clock battery are installed.



The device may be damaged if the GSM modem antenna is not connected!

The Xamelo 100 device is powered by direct current $10V \div 16V$, with an average current of 0,5A during operation, and a maximum of 0,7A.

Connecting the device:

- Install the device according to the <u>Safety instructions</u>.
- Connect the optional peripheral devices to the COM1 COM4 interfaces
- Connect the power supply to the POWER socket ensuring the correct polarity (+ and -)

The device should be equipped with a readily accessible power interruption device.



Installation and connection of peripheral devices must be done with the power supply disconnected! For direct current power supply, the manufacturer recommends using the *Security Interface One* (SIO) extension module with in-built rectifier system.

Details of how to connect the power supply are described in the chapter <u>Power supply via</u> <u>SIO extension module</u>.

6 SIO Extensions Module

The optional *Security Interface One* (SIO) extension module extends the microcomputer's functionality with additional interfaces, power supplies, and input and output ports.



Layout of the Security Interface One extension module:



Name	Description
Power IN AC	16V AC current socket
ACU A +/-	Emergency power socket - 12V battery (+ and -)
Power OUT1 +/-	Main module power out socket - 10 - 22 V DC
Power OUT2 +/-	Alarm system sensor power out socket - 10 - 14 V DC
l1 - l12	Alarm system sensor inputs
01 - 04	Programmable transmission outputs

POWER	LED diode indicating correct device operation
ERROR	LED diode indicating SIO module internal error
STATUS1-6	Programmable LED diodes depending on the Xamelo 100 module software version
WIEGAND 1-2	Wiegand interface for connecting manipulators or readers
EXTENSION SLOT	GPIO/I2C data bus for connection to main module
RESET	Device reset button

When connecting the SIO extension module to the main Xamelo 100 module, ferrites must be used on the following cables:

- for GPIO/I2C tape, ferrite with the following recommended parameters: 35Ω (for 25Mhz), 88Ω (for 100Mhz)
- for Power OUT1 power supply, ferrite with the following recommended parameters: 53Ω (25Mhz), 86Ω (100Mhz)

The I1-I12 inputs can be configured as:

- NO/NC
- 2EOL
- 3EOL
- analogue 0-255 (only I11 and I12)
- active/inactive



The resistors installed for the 3EOL inputs should have a tolerance of 1%.

Jumpers:

JP3

- open input I11 operates in analogue mode
- closed analogue mode is inactive

JP4

- open input I12 operates in analogue mode
- closed analogue mode is inactive

JP1 - port COM UART (3,3V)

- 1 GND
- 2 TXD
- 3 RXD

JP2 - select boot mode

• 1-2 normal operation

• 2-3 activate bootloader

JP6 - maximum battery charging current:

- 1-2 0,7A
- 2-3 1A

JP7

- open switch on battery tests
- closed switch off battery tests

The Xamelo 100 microcomputer is connected to the extension module via the socket *Extension Slot,* with a 20-pin wire cable.

6.1 Power supply via SIO extension module

The Security Interface One extension module can also be used to power the main Xamelo 100 module as well as alarm system sensors.

It is powered by 14-16V AC, or in emergencies by the 12V battery.



Never dispose of used batteries together with general waste. The batteries must be left at special waste collection points.

The module has two DC power outputs for powering the main Xamelo 100 module and alarm system sensors.

Layout of power supply using the SIO extension module



Power supply connection procedure:

- 1. Connect the 14-16V uzwojenia wtórnego transformer terminals to the Power IN AC terminals.
- 2. Connect the battery to the dedicated cables (red to ACU A+, black to ACU A-)
- 3. Prepare the Xamelo 100 device according to the instructions in Device connection
- 4. Connect the *Power OUT1* socket to the *Power* socket for the main module (Xamelo 100), ensuring the correct polarity on both devices (+ and -)
- 5. Connect the transformer to the 230 V AC power supply.

The main Xamelo 100 device and the SIO extension module should both be in operation.

7 System installation

The device is supplied with the manufacturer's software installed. A description of the software is available in a separate document. The description below relates to individual tailor-made software solutions.

7.1 Windows CE installation

Once the power supply has been connected, the software can be installed on the device.

- Preparing the device for the software
 - 1. Connect the device via the USB Service port to a computer with Windows XP/Vista/7 operating system.
 - 2. Remove the *Memory Lock* jumper
 - 3. Connect the power supply to the *Power* socket according to the instructions, and Windows will automatically find and install the necessary device drivers.
 - 4. Launch the Atmel SAM-BA processor programmer



5. Select the recognised connection port ("/USBserial/comXX") and the disc AT91SAM9260-EK

🐜 5AM-BA 2.12	
Select the connection :	\USBserial\COM8
Select your board :	at91sam9260-ek 💌
JLink speed :	default 🔻
JLink TimeoutMultiplier :	0 👻
	Customize lowlevel
Connect	Exit

If the default port is not recognised, the device has probably not been installed correctly. In this situation the device drivers must be reinstalled. These are available in the SAM-BA programmer installation catalogue.

- 6. Confirm your choice, and after launhcing the application, replace the *Memory Lock* jumper.
- 7. Select the *NandFlash* tab.

🐜 SAM-BA 2.12 - at9	1sam9260-ek					<u>_</u> D×
File Script File He	lp					
at91sam9260 Memory I	Display					
Start Address : 0x2000	000 Refresh	Display format				Applet traces on DBGU
Size in byte(s) : 0x100		C ascii C 8-	bit 🔿 16-bit 💽 :	32-bit		
0x00200000	0xEA000020	OxFFFFFFFF	0x00000000	0x04000000		_
0x00200010	0x0020051C	0x00000000	0x00000000	0x0000020		
0x00200020	0x00000000	0x00000000	0x00000000	0x00000000		
0x00200030	0x00000000	0x00000000	0x0000000	0x00000000		
0x00200040	0x00000000	0x00000000	0x00000000	0x00000000		
0×00200050	0*0000000	0*0000000	0*0000000	0~0000000		
Send File Name : Receive File Name :				2 2	Send File Receive File	2
Address :	0x0 Size	(For Receive File) :	0x1000 byte(s)		Compare sent file wit	th memory
Scripts						
Enable NandFlash			Execute			
loading history file	0 events added					
SAM-BA console displi (sam-ba_2.12) 1 % (sam-ba_2.12) 1 %	ay active (Tcl8.5.9	9 / Tk8.5.9)				
• •						
					\USBserial\CON	48 Board : at91sam9260-ek 🚽

- 8. Select "Enable NAND" from the options and then Execute
- 9. Clear the device NAND memory by selecting *Erase All* \rightarrow *Execute*

This

step is

🐜 SAM-BA 2.12 - at9	1sam9260-ek				_ 🗆 ×
File Script File Hel	p				
at91sam9260 Memory [Display				
Start Address : 0x2000	00 Refresh	Display format			Applet traces on DBGU
Size in byte(s) : 0x100		Cascii O 8-ł	oit 🔿 16-bit 💌 3	2-bit	
0x00200000	0xEA000020	Oxffffffff	0x0000000	0x04000000	
0x00200010	0x0020051C	0x0000000	0x0000000	0x0000020	
0x00200020	0x00000000	0x0000000	0x0000000	0x00000000	
0x00200030	0x00000000	00000000x0	0x0000000	0x00000000	
0x00200040	0x00000000	0x0000000	0x0000000	0x00000000	
1 0+00200050	0~0000000	0*0000000	0*0000000	0*0000000	
Download / Upload Fi Send File Name : Receive File Name :			(1000 buts(c)		Send File Receive File Commence of the sense
Address : ju	JXU Size (For Receive File) : [0]	x1000 byte(s)		Compare sent file with memory
			 Execute 		
loading history file SAM-BA console displa (sam-ba_2.12) 1 % (sam-ba_2.12) 1 %	0 events added ay active (Tcl8.5.9	/ Tk8.5.9)			
					\USBserial\COM8 Board : at91sam9260-ek 🚽

The clear memory option completely removes the data from the device NAND memory. recommended during first system installation.

The device is ready to receive new software.

■ Installing software

- 1. Save the first level bootloader:
 - select Send Boot File→ Execute from the list
 - set the Address as 0x0
 - select the bootloader file Firstboot.nb0
 - send the file using the option Send File

File Script File Help at91sam9260 Memory Display Start Address : 0x200000 Refresh Display format Applet traces on DBGU Size in byte(s) : 0x100 0x8Ex000020 0xFFFFFFFF 0x00000000 0x0000000 0x00200010 0x00200010 0x00000000 0x00000000 0x00000000 0x00200020 0x00000000 0x00000000 0x00000000 0x00000000 0x00200020 0x00000000 0x00000000 0x00000000 0x000000000 0x00200020 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000	駵 SAM-BA 2.12 - at9	1sam9260-ek					<u>. D ×</u>
at91sam9260 Memory Display Applet traces on DBGU Start Address : 0x200000 Refresh Display format Applet traces on DBGU Size in byte(s) : 0x100 ascii C 8-bit C 16-bit C 32-bit InfosApply 0x00200000 0xEA000020 0xFFFFFFFF 0x00000000 0x0000000 0x0020020 0x0020051C 0x00000000 0x00000000 0x00000000 0x0020020 0x00000000 0x00000000 0x00000000 0x00000000 0x00200040 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000	File Script File He	lp					
Start Address: Dx200000 Refresh Display format Applet traces on DBGU Size in byte(s): 0x100 acci 6 -bit 16 -bit 32-bit Infos Applet traces on DBGU 0x00200000 0xEA000020 0xFFFFFFF 0x0000000 0x00000000 0x00000	at91sam9260 Memory I	Display					
0x00200000 0xEFFFFFFF 0x0000000 0x0000000 0x00200010 0x00000000 0x00000000 0x00000000 0x00200020 0x00000000 0x00000000 0x00000000 0x00200030 0x00000000 0x00000000 0x00000000 0x00200040 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x0000000 0x00000000 0x00000000 Size (For Receive File)	Start Address : 0x2000 Size in byte(s) : 0x100	000 Refresh	Display format	bit O 16-bit 🖲 :	32-bit	Applet traces on DBG	su Jy
0x00200010 0x0020051C 0x0000000 0x0000000 0x0000000 0x00200020 0x0000000 0x0000000 0x0000000 0x0000000 0x00200030 0x0000000 0x0000000 0x0000000 0x0000000 0x00200040 0x0000000 0x0000000 0x0000000 0x0000000 0x00200040 0x0000000 0x0000000 0x0000000 0x0000000 0x00200040 0x0000000 0x0000000 0x0000000 0x00000000 0x00200040 0x00000000 0x0000000 0x00000000 0x00000000 0x00200040 0x00000000 0x00000000 0x00000000 0x00000000 0x00200040 0x00000000 0x00000000 0x00000000 0x00000000 0x00200040 0x00000000 0x00000000 0x00000000 0x00000000 0x0000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x0000000 0x0000000 0x0000000 0x0000000 0x0000000 0x0000000 0x0000000 0x0000000 Size (For Receive File) : 0x1000 <th>0x00200000</th> <th>0xEA000020</th> <th>OxFFFFFFFF</th> <th>0x00000000</th> <th>0x04000000</th> <th></th> <th>-</th>	0x00200000	0xEA000020	OxFFFFFFFF	0x00000000	0x04000000		-
0x0020020 0x0000000 0x0000000 0x0000000 0x0000000 0x00200030 0x0000000 0x0000000 0x0000000 0x0000000 0x00200040 0x0000000 0x0000000 0x0000000 0x0000000 0x00200040 0x0000000 0x0000000 0x0000000 0x0000000 0x00200040 0x0000000 0x0000000 0x0000000 0x00000000 0x00200040 0x00000000 0x00000000 0x00000000 0x00000000 0x0000000 0x00000000 0x00000000 0x00000000 0x00000000 0x0000000 0x00000000 0x00000000 0x00000000 0x00000000 0x0000000 0x0000000 0x0000000 0x0000000 0x0000000 0x0000000 0x0000000 Scripts Scripts Scripts Scripts	0x00200010	0x0020051C	0x0000000	0x00000000	0x0000020		
0x00200030 0x0000000 0x00000000 0x00000000 0x00200040 0x00000000 0x00000000 0x00000000 0x00200050 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x0000000 0x00000000 0x00000000 0x00000000 0x0000000 0x0000000 0x0000000 0x00000000 0x0000000 0x0000000 0x0000000 0x0000000 0x0000000 0x000000 0x0000000 0x0000000 0x0000000 0x0000000 0x0000000 0x0000000 0x0000000 0x00000000 0x0000000	0x00200020	0x0000000	0x0000000	0x00000000	0x00000000		
0x00200040 0x0000000 0x00000000 0x00000000 0x00200000 0x00000000 0x00000000 0x00000000 0x00200000 0x00000000 0x00000000 0x00000000 0x00200000 0x00000000 0x00000000 0x00000000 0x00200000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x0000000 0x00000000 0x00000000 0x00000000 0x0000000 0x00000000 0x00000000 0x00000000 0x0000000 0x0000000 0x0000000 0x000000 0x0000000 0x000000 0x00000 0x0000000 0x00000000 0x0000000 0x0000000 0x0000000 0x000 0x000 0x0000 0x000000 0x0000000 0x0000 0x00000 0x00000 0x000000 0x00000000 0x000000000000 0x0000000000	0x00200030	0x0000000	0x0000000	0x00000000	0x00000000		
Over00200050 Over0000000 Over0000000 Over0000000 DataFlash AT45DB/DCB EEPROM AT24 NandFlash NorFlash SRAM SRAM SerialFlash AT25/AT26 Download / Upload File Send File Send File Send File Receive File Receive File Name : C:/Xamelo/FIRSTBOOT.nb0 Image: Receive File Receive File Address : 0x0 Size (For Receive File) : 0x1000 byte(s) Compare sent file with memory Scripts Send Boot File Execute Execute Execute Dataling history file 0 events added Scripts Send File (Name File) NorFlash Scripts Send Boot File Execute Execute Image: Send Boot File Image: Send Boot File Sam-ba_2.12) 1 % sam-ba_2.12) 1 % sam-ba_2.12) 1 % South File (NandFlash) *** 0x0 0 Execute Image: Send File (NandFlash) **** 0x0 0 Execute Image: Send File (NandFlash) ************************************	0x00200040	0x0000000	0x00000000	0x00000000	0x00000000		
DataFlash AT45D8/DCB EEPROM AT24 NandFlash NorFlash SDRAM SRAM SerialFlash AT25/AT26 Download / Upload File Send File Send File Send File Receive File Receive File Name : Size (For Receive File) : 0x1000 byte(s) Compare sent file with memory Scripts Send Boot File Execute Oading history file 0 events added 5AM-BA console display active (Tcl8.5.9 / Tk8.5.9) sam-ba_2.12) 1 % sam-ba_2.12) 1 % send_file (NandFlash) *" 0x0 0 E- No send file name sam-ba_2.12) 1 %	0×00200050	0~0000000	0~0000000	0*0000000	0*0000000		
Address : 0x0 Size (For Receive File) : 0x1000 byte(s) Compare sent file with memory Scripts Send Boot File Execute Dading history file 0 events added Execute Execute Dading history file 0 events added Scripts Execute Execute Dading history file 0 events added Scripts = 0.12, 12, 1 % sam-ba_2.12, 1 % sam-ba_2.12, 1 % sam-ba_2.12, 1 % sam-ba_2.12, 1 % Scripts = 0.12, 12, 1 % Scripts = 0.12, 12, 1 % Scripts = 0.12, 12, 1 % Sam-ba_2.12, 1 % Sam-ba_2	Send File Name : Receive File Name :	C:/Xamelo <mark>/</mark> FIRSTBOO	T.nb0		≝ ≝	Send File Receive File	
Address : 0x0 Size (For Receive File) : 0x1000 Byte(g) Compare sent file with memory Scripts Send Boot File Execute Doading history file 0 events added Execute SAM-BA console display active (Tcl8.5.9 / Tk8.5.9) sam-ba_2.12) 1 % sam-ba_2.12) 1 % send_file {NandFlash} "" 0x0 0 E- No send file name sam-ba_2.12) 1 %	Receive File Name :	Circo -	(Eas Dassius Eile) - [<u> </u>	Receive File	
Scripts Execute Send Boot File Execute coading history file 0 events added Execute SAM-BA console display active (Tcl8.5.9 / Tk8.5.9) sam-ba_2.12) 1 % sam-ba_2.12) 1 % sam-ba_2.12) 1 % send_file {NandFlash} "" 0x0 0 E- No send file name sam-ba_2.12) 1 %	Address : j	3120	(For Receive File) ; ju	x1000 byte(s)		compare sent nie with memory	
ading history file 0 events added AM-BA console display active (Tcl8.5.9 / Tk8.5.9) sam-ba_2.12) 1 % sam-ba_2.12) 1 % send_file {NandFlash} "" 0x0 0 E- No send file name sam-ba_2.12) 1 %	Scripts Send Boot File			Execute			
	bading history file SAM-BA console displi- sam-ba_2.12) 1 % sam-ba_2.12) 1 % se E- No send file name sam-ba_2.12) 1 %	0 events added ay active (Tcl8.5.9 end_file {NandFlas	/ Tk8.5.9) h} "" 0x0 0				



The lowest level bootloader is used to launch the more advanced second level bootloader.

- 3. Save the second level bootloader:
 - select Send Boot File→ Execute from the list
 - set the Address as 0x80000
 - select the bootloader file eboot.nb0,
 - send the file using the option Send File
- 4. Save the WinCE 6.0 system picture:
 - select Send Boot File→ Execute from the list,
 - set the Address as 0x200000
 - select the bootloader file NK.nb0,
 - send the file using the option Send File







7.2 Linux installation

To install Linux software, contact the device manufacturer.

8 Device configuration

The computer does not have a graphics interface, as a result configuration of the system is carried out remotely.

■ Configuration of device with WIN CE

Remote access is possible using CERHost tools, while MobileRegistryEditor tools allow remote editing of the device registry itself.



To configure the MAC address and the device network address:

- 1. Connect the working device via USB Service to a computer
- 2. Launch the tools MobileRegistryEditor.exe and the registry of the device will be read.

🔡 Mobile Registry Editor				
File Tools				
Regsitry Favorites	Name 🔺	Data Type	Data	
Adeneo	(Default) AutoCfg AutoInterval AutoIP AutoMask AutoSeed AutoSubnet	String DWord DWord MultiString MultiString DWord MultiString	(value not set) 1 300 169.254.189.51 255.255.0.0 2703504571 169.254.0.0	
AsyncMac1 Autoras Autoras CXPort Ort EMACB MACB1 Parms Ort NE2000	BootSettings DefaultGate DhcpDefault DhcpDNS DhcpIPAddress DhcpServer DhcpSubnet DhcpWINS	DWord String MultiString MultiString MultiString MultiString MultiString	0 192.168.0.254 192.168.0.254 192.168.0.1 192.168.0.1 192.168.0.1 192.168.0.1 255.255.255.0 192.168.0.1	
	DNS Domain EnableDHCP DAddress	String String DWord String	0.0.00 next.local 0 192.168.0.231	T
HKEY_LOCAL_MACHINE\Comm\EMACB1\Parms\TcpIp 0 sub keys 27 values.				alues.

- 3. Edit the key values for the MAC address on the branch HKEY_LOCAL_MACHINE -> Comm -> EMACB1 -> Parms
 - NetworkAddress MAC address
- 4. Edit the key values for the network card on the branch HKEY_LOCAL_MACHINE -> Comm -> EMACB1 -> Parms -> Tcplp
 - EnableDHCP enable address download from DHCP server
 - IpAddress manually entered IP address
 - Subnetmask manually entered network mask
 - DefaultGateway manually entered network gate
- 5. Once you have entered the changes, restart the device.

Configuring devices with Linux

To configure a device with Linux software, contact the device manufacturer.

9 Technical information

9.1 Xamelo 100

Xamelo 100 device technical data:

Parameter	Value		
Communication interfaces	RS232 / RS485 / Ethernet (LAN) / Ethernet (WAN) / GSM		
External memory	Dependant on capacity of SD card in the device		
Optical indicators	YES, device status		
Audio indicators	YES, information about command issued		
Recommended power supply	10V ÷ 24V DC; average (during operation)/ max - 0,5A/0,7A		
Device clock battery type	CR2032 3V		
OC (01) output load	50 mA		
Range of operating temperature	5°C ÷ 40°C		
Dimensions (length x width height)	x 244 x 119 x 200 mm		
Weight	~230 gr		
Components			
Microcontroller Atmel AT91SAM9	 ARM926EJ-S Core processor with clock frequency of 200MHz 8 kB Cache memory for data and instructions 8 kB SRAM internal memory 32 kB ROM internal memory 		
SDRAM memory	5 64MB SDRAM memory		
NAND Flash memory	512MB NAND Flash memory		
Emergency battery power	CR2032 battery for maintaining actual RTC time.		
Data bus GPIO/I2C	Data bus for the external extension module		
Modem GSM Quectel M10 i	ntegrated GSM/GPRS modem via an internal RS232 nterface, working at the frequencies: 850/900/1800/1900MHz		
USB hub	USB port concentrator		
Switch	Ethernet port switch		
RS232	lormal DB9 interface socket (not TTL) - 5 wire		
1	Normal DB9 interface socket (not TTL) - 5 wire		
1	Normal DB9 interface socket - 3 wire		
RS485 I	Half-duplex RJ11 interface		
Interfaces	Maximum cable length		

NO/NC lines	100 m
GPIO/I2C	15 cm, recommended ferrites 35Ω (25Mhz), 88 Ω (100Mhz)
USB	1.5 m
RS232	5 m
RS485	100 m at 100Kb/s
WAN	twisted cable category 5 or higher - 100 m
LAN	twisted cable category 5 or higher - 100 m
power cable	2 m

9.2 SIO

Security Interface One (SIO) extension module technical data:

Parameter	Value		
Communication device<->Xamelo 100	GPIO data bus		
Event buffer	512 events recorded in a loop		
Optical indicators	YES, device status		
Audio indicators	none		
Power supply	16V AC		
Battery voltage (ACU)	12 V		
Fuses	1A 250 V		
Output voltages:			
PowerOUT1	1022 V DC		
PowerOUT2	1014 V DC		
Wiegand1 ±	1014 V DC		
Wiegand2 ±	1014 V DC		
Load:			
Transmission outputs (01-04)	1A/24V DC, 0,5A/125V AC		
PowerOUT1 power output	0,9 A		
PowerOUT2 + Wiegand1 + Wiegand2 0,9A	0,9 A		
Maximum current for battery charging	1 lub 0,7 A		
Battery malfunction voltage warning	11 V ±10%		
Battery disconnection voltage	10,5 V ±10%		
Range of operating temperature	5°C ÷ 40°C		
Dimensions (length x width x height)	184 x 108 x 47 mm		

Maximum cable length

sensor inputs

Interfaces

NO/NC	100 m
2EOL	100 m
3EOL	100 m
analogue (i11, i12)	5 m
Wiegand	2 m
GPIO/I2C	15 cm, recommended ferrites 35Ω (25Mhz), 88Ω (100Mhz)
COM (UART)	3 m
Power cable	2 m

9.3 Norms

The Xamelo 100 device and SIO extension module adhere to the following norms:

- EN50136-1:2012 Norm for alarm transmission systems level 3
- EN60950 IT devices. Safety.
- EN50082-1 Electromagnetic compatibility.
- Environmental class according to EN50130-5 level I

The concentrator meets requirements for alarm transmission according to the class (norm: PN50131-1-2006):

transmission time D3 (20 seconds) maximum transmission time M3 (60 seconds) report time T4 (180 seconds) safety S2 data security I3.

To ensure that all the above norms are met, it is necessary for all elements of the system to also meet the norms. This is particularly important for power supplies, which must be connected via the alarm system console.

